

## MOUNTING SUGGESTIONS

## Triumph Thunderbird 2009-2018 Solo and Passenger Seat

<u>Hardware:</u> Solo: Passenger:

Stock side bolts x2 6mm x 25mm hex bolt x2

Chrome spool washer x2

Tools needed: 5mm Allen wrench 8mm hex wrench

10 mm hex wrench

## Removal of stock seat:

- 1. Remove the 6mm rear screw from the fender with a 5mm Allen wrench.
- 2. Slide the passenger seat back, out of the fender bracket, and then up and off the fender.
- 3. Locate and remove the two solo seat side mounting bolts (slightly forward of the shocks) with a 5mm Allen wrench.
- 4. Lift the rear of the solo up, and then back to remove from the motorcycle.

Note: The stock passenger seat will not fit with the Mustang solo.

## Installation of Mustang seat:

1. Remove the seat bracket from the fender using an 8mm wrench, and install the supplied chrome spool washers to the fender using the supplied 6mm bolts. Tighten securely with a 10mm wrench.



- 2. Place the solo seat onto the frame and slide it forward, engaging the nose bracket into the receiver under the gas tank. Do not install the side bolts yet.
- 3. Align the passenger seat's front brackets with the spool washers on the fender. Slide the passenger seat forward until the brackets fully engage the spool washers.



4. Install the stock 6mm rear screw through the rear seat bracket and into the fender. Tighten securely with a 5mm Allen wrench.



5. Align the solo's side brackets with the mounts on either side and install the stock 6mm bolts. Tighten both finger-tight, then tighten securely with a 5mm Allen wrench.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 8:30 - 5:00 Eastern or send an e-mail to <a href="mailto:tech@mustangseats.com">tech@mustangseats.com</a> or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76830, 76831, 76832, 76833, 76834, 76835, 79816, 79817, 79818, 79824, 79825, 79826



Products made by Mustang Motorcycle Products, LLC are warranted for one year against defects in material and workmanship. Mustang must first be notified of any apparent defect. A return authorization will be issued. Carefully pack the product and return prepaid. Upon receipt, Mustang will make a fair, prompt decision regarding repair or replacement. Incidental and consequential damages arising from or in connection with the installation or use of a Mustang product are not covered by this warranty. An original purchase receipt must be provided to obtain a warranty repair or replacement.